

Instruction for use GB, Bruksanvisning NO, Instruções de uso DE, Instrucciones de uso ES, Instruções de serviço PT, Gebruiksaanwijzing NL, Brugsanvisning DK, Bruksanvisning FI, Bruksanvisning SE, Talmlaster T, Instruksje PL, Navodila SI

SKYLOTEC GmbH, Im Mühlengrund 6-8, 56566 Neuwied - Germany, Fon +49 (0)2631 9680-0, Fax +49 (0)2631 9680-60, Mail info@skylotec.com, Web www.skylotec.com

SKYLOTEC MAT-BA-0044-00, Stand 30.11.2018

Use okay/Nutzung in Ordnung, Proceed with caution during usage/Vorsicht bei der Nutzung, Danger to life/Lebensgefahr

Informationen/Information

1) Connectors/Verbindungselemente




Table with 18 columns: Product Code, Product Name, Dimensions, Standards, Certifications, Material, Weight, Force, and other technical specifications for various carabiner models.

Legend / Legende / Legenda / Légende / Leyenda / Lengenda / Forklaring / Forklaring / Forklaring / Forklaring / Forklaring / Forklaring / Forklaring / Forklaring / Forklaring / Forklaring / Forklaring / Forklaring / Forklaring / Forklaring / Forklaring / Forklaring

Warning: This equipment should not be used for any purpose other than that for which it was intended. Use of non-designated items of equipment represents a hazard in that the safe function of one item may be affected by, or interfere with, the safe function of another.

Prior to use, it has to be ensured that the clearance beneath the user is sufficient, so that in case of a fall, there will be no impact with the ground, objects, or equipment below. Check the complete personal protective equipment (PPE) and its individual components.

Safety requirements: The instructions on protecting the user and the equipment must be strictly complied with! The product label must be completely legible! It is an important requirement for the user to check all attachment and/or adjustment parts regularly during use.

Inspection and service life: A regular review of local regulations is required. In Europe, for example, an inspection by an expert is mandatory. The replacement state depends on the product, its frequency of use and the external application conditions.

Maintenance and storage: The manufacturer's liability for defective products does not include damage to property or personal injuries, which can occur even for proper functioning.

Use of non-designated equipment: The use of non-designated equipment for work purposes is not recommended. The manufacturer's liability will be rendered null and void.

Warning: Please contact the manufacturer if you have any doubt. If any facts are picked up during inspection, the product must be replaced.

1) Connectors: Before use, the connection element must be checked for any cuts, tears or damage due to deformation and wear. No additional mechanical (e.g. punched numbers, engraving, cutting) processes should be used to label the equipment.

2) Marking: (I) Manufacturer logo, (II) Item number, (III) Standard(s) and year, (IV) max. load, (V) Serial number, (VI) Note symbol 'Observe instructions for use', (VII) Conformity sign, (VIII) Series no., (IX) Month and year of manufacture.

3) Declaration of Conformity: The label for the Declaration of Conformity is available on the following website: www.skylotec.com/downloads. 4) Identification and warranty certificate: 1) Type, 2) Item no., 3) Series no., 4) Month and year of manufacture. 5) Check card: 1) To be completed for audit, 2) Tester, 3) Reason, 4) Remark, 5) Next inspection.

GB Instruction for use, DE Gebrauchsanleitung, IT Istruzioni d'uso, FR Instructions d'utilisation, ES Instrucciones de uso, PT Instruções de serviço

Warning: This equipment should not be used for any purpose other than that for which it was intended. Use of non-designated items of equipment represents a hazard in that the safe function of one item may be affected by, or interfere with, the safe function of another.

Prior to use, it has to be ensured that the clearance beneath the user is sufficient, so that in case of a fall, there will be no impact with the ground, objects, or equipment below. Check the complete personal protective equipment (PPE) and its individual components.

Safety requirements: The instructions on protecting the user and the equipment must be strictly complied with! The product label must be completely legible! It is an important requirement for the user to check all attachment and/or adjustment parts regularly during use.

Inspection and service life: A regular review of local regulations is required. In Europe, for example, an inspection by an expert is mandatory. The replacement state depends on the product, its frequency of use and the external application conditions.

Maintenance and storage: The manufacturer's liability for defective products does not include damage to property or personal injuries, which can occur even for proper functioning.

Use of non-designated equipment: The use of non-designated equipment for work purposes is not recommended. The manufacturer's liability will be rendered null and void.

Warning: Please contact the manufacturer if you have any doubt. If any facts are picked up during inspection, the product must be replaced.

1) Connectors: Before use, the connection element must be checked for any cuts, tears or damage due to deformation and wear. No additional mechanical (e.g. punched numbers, engraving, cutting) processes should be used to label the equipment.

2) Marking: (I) Manufacturer logo, (II) Item number, (III) Standard(s) and year, (IV) max. load, (V) Serial number, (VI) Note symbol 'Observe instructions for use', (VII) Conformity sign, (VIII) Series no., (IX) Month and year of manufacture.

3) Declaration of Conformity: The label for the Declaration of Conformity is available on the following website: www.skylotec.com/downloads. 4) Identification and warranty certificate: 1) Type, 2) Item no., 3) Series no., 4) Month and year of manufacture. 5) Check card: 1) To be completed for audit, 2) Tester, 3) Reason, 4) Remark, 5) Next inspection.

GB Instruction for use, DE Gebrauchsanleitung, IT Istruzioni d'uso, FR Instructions d'utilisation, ES Instrucciones de uso, PT Instruções de serviço

Warning: This equipment should not be used for any purpose other than that for which it was intended. Use of non-designated items of equipment represents a hazard in that the safe function of one item may be affected by, or interfere with, the safe function of another.

Prior to use, it has to be ensured that the clearance beneath the user is sufficient, so that in case of a fall, there will be no impact with the ground, objects, or equipment below. Check the complete personal protective equipment (PPE) and its individual components.

Safety requirements: The instructions on protecting the user and the equipment must be strictly complied with! The product label must be completely legible! It is an important requirement for the user to check all attachment and/or adjustment parts regularly during use.

Inspection and service life: A regular review of local regulations is required. In Europe, for example, an inspection by an expert is mandatory. The replacement state depends on the product, its frequency of use and the external application conditions.

Maintenance and storage: The manufacturer's liability for defective products does not include damage to property or personal injuries, which can occur even for proper functioning.

Use of non-designated equipment: The use of non-designated equipment for work purposes is not recommended. The manufacturer's liability will be rendered null and void.

Warning: Please contact the manufacturer if you have any doubt. If any facts are picked up during inspection, the product must be replaced.

1) Connectors: Before use, the connection element must be checked for any cuts, tears or damage due to deformation and wear. No additional mechanical (e.g. punched numbers, engraving, cutting) processes should be used to label the equipment.

2) Marking: (I) Manufacturer logo, (II) Item number, (III) Standard(s) and year, (IV) max. load, (V) Serial number, (VI) Note symbol 'Observe instructions for use', (VII) Conformity sign, (VIII) Series no., (IX) Month and year of manufacture.

3) Declaration of Conformity: The label for the Declaration of Conformity is available on the following website: www.skylotec.com/downloads. 4) Identification and warranty certificate: 1) Type, 2) Item no., 3) Series no., 4) Month and year of manufacture. 5) Check card: 1) To be completed for audit, 2) Tester, 3) Reason, 4) Remark, 5) Next inspection.

GB Instruction for use, DE Gebrauchsanleitung, IT Istruzioni d'uso, FR Instructions d'utilisation, ES Instrucciones de uso, PT Instruções de serviço

Warning: This equipment should not be used for any purpose other than that for which it was intended. Use of non-designated items of equipment represents a hazard in that the safe function of one item may be affected by, or interfere with, the safe function of another.

Prior to use, it has to be ensured that the clearance beneath the user is sufficient, so that in case of a fall, there will be no impact with the ground, objects, or equipment below. Check the complete personal protective equipment (PPE) and its individual components.

Safety requirements: The instructions on protecting the user and the equipment must be strictly complied with! The product label must be completely legible! It is an important requirement for the user to check all attachment and/or adjustment parts regularly during use.

Inspection and service life: A regular review of local regulations is required. In Europe, for example, an inspection by an expert is mandatory. The replacement state depends on the product, its frequency of use and the external application conditions.

Maintenance and storage: The manufacturer's liability for defective products does not include damage to property or personal injuries, which can occur even for proper functioning.

Use of non-designated equipment: The use of non-designated equipment for work purposes is not recommended. The manufacturer's liability will be rendered null and void.

Warning: Please contact the manufacturer if you have any doubt. If any facts are picked up during inspection, the product must be replaced.

1) Connectors: Before use, the connection element must be checked for any cuts, tears or damage due to deformation and wear. No additional mechanical (e.g. punched numbers, engraving, cutting) processes should be used to label the equipment.

2) Marking: (I) Manufacturer logo, (II) Item number, (III) Standard(s) and year, (IV) max. load, (V) Serial number, (VI) Note symbol 'Observe instructions for use', (VII) Conformity sign, (VIII) Series no., (IX) Month and year of manufacture.

3) Declaration of Conformity: The label for the Declaration of Conformity is available on the following website: www.skylotec.com/downloads. 4) Identification and warranty certificate: 1) Type, 2) Item no., 3) Series no., 4) Month and year of manufacture. 5) Check card: 1) To be completed for audit, 2) Tester, 3) Reason, 4) Remark, 5) Next inspection.

GB Instruction for use, DE Gebrauchsanleitung, IT Istruzioni d'uso, FR Instructions d'utilisation, ES Instrucciones de uso, PT Instruções de serviço

Warning: This equipment should not be used for any purpose other than that for which it was intended. Use of non-designated items of equipment represents a hazard in that the safe function of one item may be affected by, or interfere with, the safe function of another.

Prior to use, it has to be ensured that the clearance beneath the user is sufficient, so that in case of a fall, there will be no impact with the ground, objects, or equipment below. Check the complete personal protective equipment (PPE) and its individual components.

Safety requirements: The instructions on protecting the user and the equipment must be strictly complied with! The product label must be completely legible! It is an important requirement for the user to check all attachment and/or adjustment parts regularly during use.

Inspection and service life: A regular review of local regulations is required. In Europe, for example, an inspection by an expert is mandatory. The replacement state depends on the product, its frequency of use and the external application conditions.

Maintenance and storage: The manufacturer's liability for defective products does not include damage to property or personal injuries, which can occur even for proper functioning.

Use of non-designated equipment: The use of non-designated equipment for work purposes is not recommended. The manufacturer's liability will be rendered null and void.

Warning: Please contact the manufacturer if you have any doubt. If any facts are picked up during inspection, the product must be replaced.

1) Connectors: Before use, the connection element must be checked for any cuts, tears or damage due to deformation and wear. No additional mechanical (e.g. punched numbers, engraving, cutting) processes should be used to label the equipment.

2) Marking: (I) Manufacturer logo, (II) Item number, (III) Standard(s) and year, (IV) max. load, (V) Serial number, (VI) Note symbol 'Observe instructions for use', (VII) Conformity sign, (VIII) Series no., (IX) Month and year of manufacture.

3) Declaration of Conformity: The label for the Declaration of Conformity is available on the following website: www.skylotec.com/downloads. 4) Identification and warranty certificate: 1) Type, 2) Item no., 3) Series no., 4) Month and year of manufacture. 5) Check card: 1) To be completed for audit, 2) Tester, 3) Reason, 4) Remark, 5) Next inspection.

GB Instruction for use, DE Gebrauchsanleitung, IT Istruzioni d'uso, FR Instructions d'utilisation, ES Instrucciones de uso, PT Instruções de serviço

Warning: This equipment should not be used for any purpose other than that for which it was intended. Use of non-designated items of equipment represents a hazard in that the safe function of one item may be affected by, or interfere with, the safe function of another.

Prior to use, it has to be ensured that the clearance beneath the user is sufficient, so that in case of a fall, there will be no impact with the ground, objects, or equipment below. Check the complete personal protective equipment (PPE) and its individual components.

Safety requirements: The instructions on protecting the user and the equipment must be strictly complied with! The product label must be completely legible! It is an important requirement for the user to check all attachment and/or adjustment parts regularly during use.

Inspection and service life: A regular review of local regulations is required. In Europe, for example, an inspection by an expert is mandatory. The replacement state depends on the product, its frequency of use and the external application conditions.

Maintenance and storage: The manufacturer's liability for defective products does not include damage to property or personal injuries, which can occur even for proper functioning.

Use of non-designated equipment: The use of non-designated equipment for work purposes is not recommended. The manufacturer's liability will be rendered null and void.

Warning: Please contact the manufacturer if you have any doubt. If any facts are picked up during inspection, the product must be replaced.

1) Connectors: Before use, the connection element must be checked for any cuts, tears or damage due to deformation and wear. No additional mechanical (e.g. punched numbers, engraving, cutting) processes should be used to label the equipment.

2) Marking: (I) Manufacturer logo, (II) Item number, (III) Standard(s) and year, (IV) max. load, (V) Serial number, (VI) Note symbol 'Observe instructions for use', (VII) Conformity sign, (VIII) Series no., (IX) Month and year of manufacture.

3) Declaration of Conformity: The label for the Declaration of Conformity is available on the following website: www.skylotec.com/downloads. 4) Identification and warranty certificate: 1) Type, 2) Item no., 3) Series no., 4) Month and year of manufacture. 5) Check card: 1) To be completed for audit, 2) Tester, 3) Reason, 4) Remark, 5) Next inspection.

